



ISaGRAF-256 Quick Start

V1.1, Feb. 2020

Technical Support

Download ISaGRAF-256 and USB Driver

http://ftp.icpdas.com/pub/cd/ISAGRAF/ISaGRAF_256_V355.zip

<http://ftp.icpdas.com/pub/cd/ISAGRAF/Sentinel/SSD5411-32bit.exe>

ISaGRAF Website

http://www.icpdas.com/root/product/solutions/softplc_based_on_pac/isagraf/isagraf.html



1 Installing the Software

After downloading **ISaGRAF_256_V355.zip**, extracting the file and start the installation.

2 Installing the Driver of ISaGRAF USB Dongle

- 1) Un-plug ISaGRAF USB Dongle from your USB port first, and run “\Sentinel\SSD5411-32bit.exe” that be downloaded on FTP.
- 2) After completing the installation, reset the PC.
- 3) Plug the USB Dongle in the PC's USB port before running ISaGRAF-256 V3.55.