

Procedure to reset clock on I-7188E series controller

1. Install MiniOS7 on the PC using the following CD path

D:\Napdos\MiniOS7\utility\MiniOS7_utility\
or online path


ftp://ftp.icpdas.com/pub/cd/8000cd/napdos/minios7/utility/minios7_utility/

“minios7_utility_v321.exe” is the newest version.

2) Connect init* terminal to GND terminal.

3) Turn on power

4) Connect with MiniOS7 Utility



5) Set Date and Time



6) Power off and remove wire from init* to GND.